

Washing machine WLL...



en Instruction Manual and Installation Instructions

Your new washing machine

You have chosen a Bosch washing machine.

Please take a few minutes to read and become familiar with the advantages of your washing machine.

To meet the high quality demands required by Bosch, every washing machine that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.boschhome.com or contact our after-sales service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before switching on the washing machine.

Display rules

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

Note/tip

Information about the optimum use of the appliance/any other useful information.

1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

_ / -

Lists are represented by a small box or a dash.

Contents

Intended use4	P+ Programme default settings25
Safety instructions5	Temperature
Children/people/pets 5	Finished in-time
Installation6 Operation8	P+ Additional programme settings26
Cleaning/Maintenance 10	Speed Eco Perfect26
Environmental protection 11	Easy-Iron
Packaging/used appliance11	Prewash
Tips on economical use 11	Operating the appliance 27
Positioning and connecting11	Preparing the washing machine 27
Included with the appliance 11	Select programme/switch on the appliance
Safety instructions	Change the programme default settings
Installation on a base or a wooden joist	Select additional programme settings27
floor	Placing laundry into the drum 27
	Measure and add detergent and care products
Removing the transport locks13 Hose and cable lengths14	Start the programme
Water inlet	Childlock
Water outlet	Soaking
Electrical connection17	Changing the programme
Before washing for the first time17 Transportation18	Cancel the programme
· ·	Programme end30
Getting to know the appliance 19	Removing laundry/switching off the appliance
Washing machine	
Display panel 21	•))) Sensors
Laundry23	Automatic load sensing31 Unbalanced load detection system31
Prepare the laundry	VoltCheck
Sorting laundry 23	Appliance settings31
Starching	
Dyeing/bleaching 24	Cleaning and maintenance32
Detergent24	Machine housing/control panel33 Drum33
Correct selection of detergent 24 Saving energy and detergent 24	Descaling
	Detergent drawer and nousing 33

Intended use en



Intended use

- This appliance is intended for private domestic use only.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoor conditions. There is a risk that the appliance will be damaged if residual water in it freezes. If hoses freeze up, they may crack/burst.
- This appliance must only be used for washing domestic laundry, consisting of machine-washable items and hand-washable woollens (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance is suitable for operation with mains water and commercially available detergents and care products (must be suitable for use in washing machines).
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.

Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

Read and follow the operating and installation instructions and all other information provided with this appliance.

Retain the documents for subsequent use or for subsequent owners.

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

Children/people/pets

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance.
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate.

Keep packaging, plastic film and packing components away from children.

⚠ Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

If accidentally swallowed, seek medical advice. Keep detergents and care products out of the reach of children.

When washing at high temperatures, the glass in the appliance door becomes hot. Stop children from touching the appliance door when it is hot.

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

Installation

If the appliance is not installed properly, this may lead to a

dangerous situation. Ensure the following:

- The mains voltage on your power socket must match the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The mains plug and the protective contact socket must match and the earthing system must be correctly installed.
- The installation must have an adequate cross section.
- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (all pole disconnection) must be built into the permanent installation in accordance with electrical installation regulations.
- If using a residual current circuit breaker, only use one that bears the following mark: . The presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

↑ Warning Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

Marning

Risk of fire/material damage/damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.

Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.

If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury. Do not take hold of any of the appliance's protruding parts in order to move the appliance.

- The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
 Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.
 Route hoses and cables such that they do not constitute a tripping hazard.

Caution! Material damage/damage to the appliance

- If the water pressure is too high or too low, the appliance may not be able to operate properly, and it may also result in material damage or damage to the appliance.

 Make sure that the water pressure in the water supply facility is at least 100 kPa (1 bar), and does not exceed 1000 kPa (10 bar).
- If the water hoses are altered or damaged, this may result in material damage or damage to the appliance. The water hoses must not be kinked, crushed, altered or severed.
- The use of hoses supplied by other brands to connect to the water supply may result in material damage or damage to the appliance. Use the hoses supplied with the appliance or genuine spare part hoses only.

The appliance is secured for transportation by transport locking devices. If the transport locking devices are not removed before the appliance is operated, this may result in damage to the appliance. It is important to completely remove all transport locking devices before using the appliance for the first time. Make sure that you retain these transport locking devices separately. It is important to refit the transport locking devices if the appliance is to be transported, in order to prevent the appliance from being damaged in transit.

Operation

Laundry that has been pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion in the drum. Rinse the laundry thoroughly with water before washing it in the machine.

⚠ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

- If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.
 - Do not support your weight on the appliance door when it is open.
- If you climb onto the appliance, the worktop may break, which may result in injury.
 Do not climb onto the appliance.
- If you reach into the drum while it is still rotating, you risk injuring your hands. Wait until the drum has stopped rotating.

When washing at high temperatures, there is a risk of scalding if you come into contact with hot detergent solution (e.g. when draining hot detergent solution into a washbasin).

Do not reach into the hot detergent solution.

⚠ Warning Eye/skin irritation!

Detergent and care products may spray out if the detergent

drawer is opened while the appliance is in operation. Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. If accidentally swallowed, seek medical advice

Caution! Material damage/damage to the appliance

- If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.
 Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs → Supplementary sheet for the operating and installation instructions.
- If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.

Cleaning/Maintenance

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.
- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer, steam cleaner, hose or spray gun to clean your appliance.

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

Caution! Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

 Do not allow these agents to come into contact with the surfaces of the appliance.

- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.



Packaging/used appliance



Dispose of packaging in an environmentally-responsible manner.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Tips on economical use

- Always utilise the maximum amount of washing for the particular programme.
 Overview of programmes → Supplementary sheet for the operating and installation
- instructions.Wash normally soiled laundry without prewash.
- For light and normal soiling in laundry, you can save energy and detergent. → Page 24

- The selectable temperatures apply to the care labels on the textiles. The temperatures in the machine may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Information about the energy consumption*:

The display provides information about the relative energy consumption in the selected programs.

The more indicator lights light up, the higher the program's consumption.

This enables you to compare the consumption levels of the different programs when choosing your program settings and to decide on an energy- and water-saving program setting.


- Energy-saving mode: The display panel light goes out after several minutes, Start button flashes. Press any button to activate the light. Energy-saving mode is not activated if a programme is running.
- If the washing will be dried in a dryer, select the spin speed according to the dryer manufacturer's instructions.

Positioning and connecting

Included with the appliance

Note: Check the machine for transport damage. Never use a damaged machine. If you have any complaints, contact the dealer from whom you purchased the appliance or our Customer Service. \rightarrow *Page 39*

* depending on the model



- 1 Mains lead
 2 Bag:
 - Installation and operating instructions
 - Customer Service location directory*
 - Warranty*
 - Cover caps for openings after the transport braces have been removed
- 3 Water inlet hose on aquaStop models
- 4 Water outlet hose
- 5 Elbow for securing the water outlet hose*
- 6 Cold water inlet hose on Standard/Aqua-Secure models
- * Depending on the model

In addition, a hose clamp (24 - 40 mm diameter, available from specialist retailers) is required to connect the water outlet hose to a siphon.

Useful tool

Spirit level for aligning

- Wrench with:
 - WAF13 for loosening the transport braces and
 - WAF17 for aligning the appliance feet

Safety instructions

⚠ Warning Risk of injury!

- The washing machine is very heavy. Be careful when lifting/transporting the washing machine.
- When the washing machine is lifted by its protruding parts (e.g. the washing machine door), the components may break off and cause injuries.
 Do not lift the washing machine by protruding parts.
- If the hose and mains cables are not routed properly, there is a risk of tripping and injury.
 Lay hoses and cables in such a way that there is no risk of tripping.

Caution! Damage to the appliance

Frozen hoses may rip/burst.
Do not install the washing machine in areas exposed to frost or outdoors.

Caution! Water damage

The connection points for the water supply hose and water drain hose are under high water pressure. To prevent leaks and water damage, you must follow the instructions in this section.

Notes

- In addition to the safety information listed here, the local water and electricity supplier may have special requirements.
- If in doubt, have the appliance connected by a specialist.

Installation surface

Note: The washing machine be stable so that it does not move around.

- The installation surface must be firm and level.
- Soft floors/floor coverings are not suitable.

Installation on a base or a wooden joist floor

Caution! Damage to the appliance

The washing machine may "wander" and tip/topple from the base when spinning.

The feet of the appliance must be secured with holding brackets. Order no. WMZ 2200, WX 9756, Z 7080X0

Note: On wooden joist floors, install the washing machine:

- In a corner, if possible,
- On a water-resistant wooden board (min. 30 mm thick) which is screwed tightly to the floor.

Installing the appliance in a kitchenette

There is a risk of electric shock if you touch live components.

Do not remove the appliance covering plate.

Notes


- Recess width of 60 cm required.
- Only install the washing machine underneath a continuous worktop that is securely connected to adjacent cabinets.

Removing the transport locks


Caution! Damage to the appliance

- The machine is secured for transportation using transport locks. If the transport locks are not removed, the drum, for example, may become damaged when the machine is operated. Before using the appliance for the first time, make sure that you completely remove all four transport locks. Keep the locks in a safe place.
- To prevent transport damage from occurring if the appliance is moved at a later date, you must refit the transport locks before transporting the appliance.

Note: Keep the screws and sleeves in a safe place.




1. Take the hoses out of the holders.




en Positioning and connecting

 Unscrew and remove all four transport brace screws.
 Remove the sleeves. To do this, remove the mains cable from the holders.




3. Fit the covers. Lock the covers firmly in place by applying pressure to the snap-in hooks.




Hose and cable lengths

Left-hand connection



Right-hand connection



Tip: The following are available from specialist dealers/the after-sales service:

- An extension for Aqua-Stop or cold water supply hose (approx. 2.50 m); order no. WMZ2380, WZ10130, CZ11350, Z7070X0
- A longer supply hose (approx. 2.20 m) for standard model

Water inlet

Notes

- Do not bend, squash, modify or cut through the water supply hose (otherwise its strength is no longer guaranteed).
- Only tighten the screw connections by hand. If the screw connections are tightened too much with a tool (pliers), the thread may become damaged.


Optimum water pressure in the mains: 100-1000 kPa (1-10 bar)

- When the tap is open, the water flow is at least 8 l/min.
- If the water pressure is higher than this, a pressure-reducing valve must be installed


Connection

Connect the water supply hose to the water tap ($\frac{3}{4}$ " = 26.4 mm) and to the appliance (not necessary for Aqua-Stop models):

Aquastop



Standard



Carefully turn on the tap and check that the connection points are not leaking.

Note: The screw connection is under water pipe pressure.

Water outlet

Caution! Water damage

If the drain hose slips out of the wash basin or the connection point during draining due to high water pressure, any escaping water may cause water damage.

Secure the drain hose so that it cannot slip out.

Note: Do not kink the water drain hose or put strain on it lengthways.

You can lay the water drain hose as follows:

Outlet in a sink

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot detergent solution e.g. if hot detergent solution is being drained into a wash basin.

Do not reach into the hot detergent solution.

Caution!


Damage to the appliance/fabrics

If the end of the drain hose is immersed in the drained water, water may be sucked back into the appliance and may damage the appliance/fabrics.

en Positioning and connecting

Make sure that:

- The plug does not block drainage from the sink.
- The end of the drain hose is not immersed in the drained water.
- The water drains away quickly enough.






Drainage into a siphon

The connection point must

The connection point must be secured using a hose clamp with a diameter of 24-40 mm (available from specialist dealers).



 Outlet into a plastic pipe with rubber bushing or into a drainage pit



Levelling

Level the appliance using a spirit level. Incorrect levelling may result in intense noise, vibrations and "wandering".

- Loosen the lock nuts using a wrench, by turning it in a clockwise direction.
- Check the alignment of the washing machine with a spirit level, and adjust it if necessary. Change the height by turning the appliance feet. All four appliance feet must stand firmly on the ground.
- Tighten the lock nut against the housing.
 In doing so, hold the foot tight and do not adjust its height.
 The lock nuts on all four appliance feet must be screwed tightly against the housing.



Electrical connection

There is a risk of electric shock if you touch live components.

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable by the plug and never by the cable, as this could damage it.
- Never unplug the mains plug during operation.

Observe the following information and ensure that:

Notes

- The mains voltage and voltage indicated on the washing machine (rating plate) are the same.
 The connected load and fuse required are specified on the rating plate.
- The washing machine is only connected to an alternating current via a properly installed earthed socket.
- The mains plug fits the socket.
- The cable cross-section is adequate.
- The earthing system is properly installed.
- The mains cable is only replaced by a qualified electrician (if this is necessary). Replacement mains cables are available from the aftersales service.
- No multiple plugs/couplings or extension cables are used.

- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (2-pole switch-off) must be built into the permanent installation in accordance with electrical installation regulations.
- The mains cable is not bent, squashed, modified, cut through, or in contact with heat sources.

Before washing for the first time

The washing machine was thoroughly tested before leaving the factory. To remove any water that may be left over from the test, run the first wash cycle without any laundry.

Notes

- The washing machine must be correctly installed and connected. (from → Page 11).
- Never use a damaged machine. Inform customer services.
- 1. Check the machine.
- Remove the protective film from the control panel.
- 3. Connect the mains plug.
- 4. Turn on the tap.
- 5. Close the door (do not load any laundry).
- 6. Depending on the model, run the

 [⊕] Drum Clean 90 °C or

 [♠] Cottons 90 °C program.
- 7. Open the detergent drawer.
- 8. Pour approximately 1 litre of water into compartment II.
- 9. Pour standard detergent into compartment II.
 - **Note:** To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergent designed for wool or delicates.
- 10. Close the detergent drawer.
- 11. Press the DM button.

12. When the program ends, switch off the appliance.

Your washing machine is now ready to use.

Transportation


e.g. when moving home

Preparatory work:


- 1. Turn off the water tap.
- Reduce the water pressure in the supply hose.
 Maintenance filter in the water supply → Page 34
- Drain the remaining detergent solution.
 Maintenance – detergent solution
- pump blocked → Page 33
 4. Disconnect the washing machine
- 4. Disconnect the washing machine from the mains.
- 5. Remove the hoses.

Installing the transport locks:

 Remove the covers and keep them in a safe place. Use a screwdriver if necessary.



Insert all four sleeves. Clip the mains cable securely in the holders. Insert and tighten the screws.




Before switching on the appliance again:

Notes

- The transport braces must be removed.
- To prevent unused detergent from flowing into the outlet during the next wash: Pour approx. 1 litre of water into compartment II and start the ⑤ Spin/ ⑥ Drain/Empty programme (if only a drain cycle is required, set rpm (spin speed) to 0 -).

Getting to know the appliance


Washing machine




- Detergent drawer
- Operating/display panel
- Loading door with door handle
- 1 2 3 3a Open the loading door
- Close the loading door 3b
- Service flap

Control panel

Control panel depends on the model






Note: The buttons are sensitive, they only need to be touched gently.

- 1 Programs
 You can find an overview of all programs on the printed
 - programs on the printed supplement for the installation and operating instructions.
- 2 Program selector:
 - for selecting a program
 - for switching the washing machine on and off via the Off position
- 3 Display panel with buttons and displays

Display panel



But- ton	Display indicator	Description
1		Selectable Temperature
	* -90°C	in °C; ≉ = cold
2		Selectable Spin speed
	, 0 - 1200** ©	in U/min; 0 = no spin cycle, draining only; = Rinse Stop
** de	epending on t epending on t ngs and mode	he selected programme, set-

But- ton		Display indicator	Description
3]		Finished in-time
		e. g. 2:30	Programme duration depends on the programme selection in h:min (hours:minutes)
	1-24 🕲	End of programme ("Ready in" time) afterh (hours)	
			program to finish after hours
		pending on th pending on th	ne model ne selected programme, set-

tings and model

en Getting to know the appliance

But- ton	Display indicator	Description
4		Additional programme settings: → Page 26
	= ₩	Speed Eco Perfect
	£	Water&Rinse+
		Prewash*
	<u>a</u>	Easy-Iron*
5	▷ 00	Button for starting a programme, interrupting a programme, e.g. to add items of laundry, and cancelling a programme
** de	pending on the pending on the gs and mode	ne selected programme, set-

More information on the display pane

Display in- dicator		Description
6,5** kg		Load recommendation
		Programmfortschritt:
	End	Programme end
	©	Programme end during Rinse Stop
©		Washing machine door
		→ "Adding laundry" on page 29
		→ "? Faults and what to do about them." on page 35
		Тар
		→ "? Faults and what to do about them." on page 35
* dependin ** dependin tings and	ig on the	model selected programme, set-

Display in- dicator	Description
Cm	Childproof lock
	→ "Childlock" on page 29
	→ "? Faults and what to do about them." on page 35
©	Indicator lamp for ⊙° Drum Clean programme*
	→ "Information on the display panel" on page 36
	→ " Appliance set- tings" on page 31
E:	Fault display
	→ "Information on the display panel" on page 36
8- 4	Signal setting
	→ " Appliance settings" on page 31
 depending on the model depending on the selected programme, settings and model 	

Laundry

Prepare the laundry


Caution!

Damage to the appliance/fabrics

Foreign objects (e.g. coins, paperclips, needles, nails) may damage the laundry or components in the washing machine.

You should therefore note the following tips when preparing your laundry:

Empty any pockets.



- Look out for metal items (paperclips, etc.) and remove them.
- Wash delicates in a laundry bag (tights, underwired bras, etc.).
- Close any zips; button up any cover buttons.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place curtains in a laundry bag.

Sorting laundry

Sort your laundry according to the care instructions and manufacturer's information on the care labels, depending on:

- Type of fabric/fibre
- Colour

Note: Laundry can discolour or not be cleaned correctly. Wash white and coloured items separately. Wash new coloured items separately the first time you wash them.

- Soiling
 - Wash laundry with the same level of soiling together. Some examples of soiling levels can be found in the chapter → Page 24
 - Light: Do not prewash; if necessary, select the additional programme setting = Speed.
 - Normal
 - Heavy: Load less laundry, select a programme with prewash.
 - Stains: Remove/pretreat stains while they are still fresh. First dab with soapy water; do not rub. Then wash the items of laundry with the appropriate programme.
 Stubborn or dried-in stains can sometimes only be removed by washing several times.
- Symbols on the care labels
 Note: The numbers in the symbols indicate the maximum washing temperature that may be used.
 - Suitable for normal washing process;
 - e.g. Cottons programme

 A gentle washing process is required:
 - e.g. Easy Care programme
 An especially gentle washing process is required; e.g.
 Delicates/Silk programme
 - Suitable for washing by hand; e.g. Wool program
 - Do not machine wash.

Starching

Note: Laundry should not be treated with fabric softener.

Liquid starch can be used to stiffen fabrics particularly in the Rinse and Cottons programmes. Measure starch into compartment & in accordance with the manufacturer's instructions (clean first if necessary).

Dyeing/bleaching

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions.

Do **not** use the washing machine to bleach clothes.

Detergent

Correct selection of detergent

The care label is crucial for selecting the correct detergent, temperature and treatment of the laundry. → See also www.sartex.ch

If you visit www.cleanright.eu, you will find further information on detergents, care products and cleaning agents for domestic use.

Standard detergent with optical brighteners

Suitable for boil-washable white laundry made from linen or cotton Programme: Cottons/cold - max. 90 °C

- Detergent for colours without bleach or optical brighteners Suitable for coloured laundry made from linen or cotton Programme: Cottons/ cold - max, 60 °C
- Detergent for colours/delicates without optical brighteners Suitable for coloured laundry made from easy-care fibres, synthetic fibres Programme: Easy-Care/ cold - max. 60 °C
- Detergent for delicates
 Suitable for delicate, fine fabrics, silk or viscose
 Programme: Delicate/Silk/cold max. 40 °C

Detergent for woollens Suitable for wool

Wool programme/ cold - max. 40 °C

Saving energy and detergent

For light and normal soiling, you can save energy (lower washing temperature) and detergent.

Soiling/note Saving Reduced temper-Liaht ature and deter-No visible dirt or stains. Clothgent quantity as ing has taken on some body per the recomodour. e.a.: mended dosage Light summer/sports clothing (worn for a few hours) T-shirts, shirts, blouses (worn for up to one day) Guest bed linen and hand towels (used for one day) Normal Visible dirt or a few light stains, e.g.: T-shirts, shirts, blouses (sweat soaked, worn a few times) Towels, bedding (used for up to one week) Temperature as Heavy per the care label Dirt and/or stains clearly visiand detergent ble, e.g. tea towels, baby quantity as per items, work clothing the recom-

Note: When measuring the amount of all detergents/additives/care products and cleaning agents, please always check the manufacturer's instructions and information. → *Page 28*

mended dosage

for heavy soiling

P+ Programme default settings

The default program settings are displayed on the display panel once the program has been selected.

You can change the default settings.

To do this, repeatedly press the corresponding button until the required setting value is displayed on the display panel.

Note: Pressing and holding the button will allow you to automatically scroll through all the setting values to the last value. Pressing it again will allow you to change the setting values again.

You can find an overview of all possible program settings on the supplementary sheet for the installation and operating instructions.

Temperature

(°C)

Button depending on the model

Depending on what stage the program is in, you can change the set temperature before and during the program.

The maximum temperature that can be set depends on the program that has been selected.

Spin speed

(©)

Depending on how far through the program the appliance is, you can change the spin speed (in rpm – revolutions per minute) before and during the program.

Setting 0: No final spin; the water is simply pumped out. The laundry stays

wet inside the drum, e.g. for items that are not to be spun.

---- **setting**: Rinse Stop = no final spin; the laundry stays in the water after the final rinse.

You can select "Rinse Stop" to prevent creasing if the laundry will not be taken out of the washing machine immediately after the program has ended.

To resume/end the program

→ Page 30

The maximum speed that can be set depends on the model and the program that has been selected.

Finished in-time

(D)

Before starting the program, you can preselect the program end time ("Ready in" time) in hourly increments (h = hour), up to a maximum of 24 hours.

To do this:

- Select a program.
 The program duration will be displayed for the selected program, e.g. 2:30 (hours:minutes).
- Press the Finished in-time button repeatedly until the required number of hours is displayed.
- Press the D button.
 The program will now start.
 The selected number of hours (e.g. 8 h) is shown on the display panel and counts down until the wash program starts. The duration of the program will then be displayed.

Note: The program duration is automatically adjusted when the program is running. Certain factors can affect the program duration, e.g.:

- Program settings,
- Detergent dosage (additional rinse cycles may be required due to foaming),

- Load size/type of fabrics (water absorption differs),
- Imbalances (e.g. due to fitted sheets) are eliminated by rotating the drum briefly several times,
- Fluctuations in power supply,
- Water pressure (inflow rate).

Once the program has been started,

you can change the preselected number of hours as follows:

- 1. Press the DII button.
- 2. Use the **Finished in-time** button to change the number of hours.
- 3. Press the DII button.

Once the program has been started, you can add more laundry or remove laundry as required. → Page 29

Pf Additional programme settings

You can find an overview of all the possible additional settings on the printed supplement for the installation and operating instructions.

The settings vary depending on the model.

Speed Eco

(=Ü ®)

Button with two possible settings for adapting the selected program:

Speed

Washing in a shorter time while achieving a washing result that is consistent with, but uses more energy than, the selected program, without the Speed Eco setting.

Note: Do not exceed the maximum load.

Eco

Energy-optimised washing by reducing the temperature while achieving a washing result that is consistent with the selected program, without the Speed Eco Perfect setting.

Press the button to do this. First of all, you can select the **Speed** setting. If you press the button again, the **Eco** setting is active. The respective symbol is shown in the display when the setting is activated.

If you press the button again, no setting is active.

Easy-Iron

(<u>国</u>)

Button depends on the model Reduces creasing by means of a special spin sequence followed by fluffing and reduced spin speed.

Note: The laundry retains an elevated level of residual moisture.

Water&Rinse+

(£)

Button depends on the model

Higher water level and additional rinse cycle for particularly sensitive skin and/or for areas with very soft water.

Prewash

(**J**)

Button depending on the model For heavily soiled laundry.

Note: Pour detergent into compartments **I** and **II**.

Operating the appliance

Preparing the washing machine

Note: The washing machine **must be correctly installed** and **connected**.

→ Page 11

- 1. Plug into the mains.
- 2. Turn on the tap.
- 3. Open the washing machine door.
- **4.** Check that the drum is completely drained. Drain if necessary.





Select programme/switch on the appliance

Note: If you have activated the childproof lock, you must first deactivate it before you can set a program.

Use the program selector to select the required program. Can be rotated in either direction.

The appliance is switched on.

The **program default settings** for the selected program appear in the display panel:

- Temperature*,
- The maximum load and the duration of the program (alternately)
- Energy consumption*.

Change the programme default settings

You can use or change the default settings for this wash cycle.

To do this, repeatedly press the corresponding button until the required setting is displayed.

The settings are activated without needing to be confirmed.

The settings are not retained after the washing machine is switched off.

Default program settings → Page 25

Select additional programme settings

By selecting additional settings, you can better adapt the washing process to the items of laundry you are washing.

The settings can be selected or deselected depending on how far the program has progressed.


The button indicator lights will be lit if a setting has been activated.

The settings are not retained after the washing machine is switched off.

Additional program settings

→ Page 26

Placing laundry into the drum




Items of laundry pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion after being loaded into the washing machine. Hand-rinse these items of laundry thoroughly beforehand.

Notes

- Mix items of laundry of varying sizes. Laundry items of different sizes distribute themselves better during the spin cycle. Individual laundry items may cause an unbalanced load.
- Observe the maximum indicated load. Overfilling adversely affects the washing result and encourages creasing.
- 1. Unfold presorted laundry items and place them in the washing drum.
- Make sure that no items of laundry are trapped between the door and the rubber seal, and close the door.





Measure and add detergent and care products

Caution! Damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the washing machine. Do not allow these agents to come into contact with the surfaces of the washing machine. If necessary, immediately wipe away spray residue and other residues/droplets with a damp cloth.

Dosing

Dose detergents and care products according to:

- The water hardness (ask your water supply company)
- The manufacturer's instructions on the packaging

- The amount of laundry
- Soiling

Filling

1. Pull out the detergent drawer.



Eye/skin irritation!


Detergent and care products may run out if the detergent drawer is opened while the machine is in operation.

Open the drawer carefully.
Rinse eyes/skin thoroughly if they come into contact with detergents or care products.

If swallowed accidentally, seek

If swallowed accidentally, seek medical advice.

2. Add detergent and/or care products.



Dispenser **I** Dispenser **%**

Detergent for prewash Softener, starch. Do not exceed maximum dose

Dispenser II

Detergent for main wash, water softener, bleach, stain remover

Notes

- When measuring the amount of all detergents, additives, care products and cleaning agents, always follow the manufacturer's instructions.
- Dilute thick-consistency fabric softener and fabric conditioner with a little water. This will prevent blockages.
- Pour liquid detergent into corresponding dispenser and place in drum.

Start the programme

Press the DM button. The indicator lamp lights up and the program starts.

Note: You will need to press and hold the DII button to start the programme. This prevents the programme from being started if something accidentally brushes against the button.

The display panel shows the Ready in time while the program is running or the program duration and the program progress symbols once the wash cycle has started.

Display panel → Page 21

If you want to lock the program to prevent it from being inadvertently adjusted, you can select the childproof lock as follows.

Childlock

 $(\sim 3 \text{ sec})$

You can lock the washing machine to prevent the functions you have set from being changed inadvertently. To do this, activate the childproof lock once the program has started.

To activate/deactivate, press and hold the Spin speed and Finished in-time buttons at the same time for approx. 3 seconds. The □ symbol will appear on the display panel.

- it up: The childproof lock is active.
- Glashing: The childproof lock is active and the program selector has been adjusted. To deactivate the childproof lock, reset the program selector to the initial program. The symbol will light up again.
 Note: Do not turn the program

Note: Do not turn the program selector beyond the "off" position, otherwise the program will stop.

Note: The childproof lock remains active after the program has ended and

the appliance is switched off. You must deactivate the childproof lock whenever you want to start a new program.

Soaking

You can soak the washing after selecting the desired program:

- 1. Pour soaking agent/detergent into compartment II in accordance with the manufacturer's instructions.
- 2. Press the **>** button. The program starts.
- 4. Leave the laundry to soak for as long as required, then either press the Dℍ button again to continue the program or change the program.

Notes

- Load laundry of the same colour.
- No additional detergent is required; the soaking solution is used for washing.

Adding laundry

Once the program has been started, you can add more laundry or remove laundry as required.

Press the DII button to do this.

The DII button indicator light will flash and the machine will check whether it is possible to add more laundry.

lf

- the symbol goes out on the display panel, it is possible to add more laundry.
- the Symbol lights up on the display panel, it is not possible to add more laundry.

To resume the program, press the D

button. The program will resume
automatically.

Notes

- Do not leave the door open for too long when adding more laundry as water from the laundry may leak out.
- For safety reasons, the door remains locked when the water level or temperature is high, or while the drum is turning, and it is not possible to add more laundry during this time.
- The load weight notification is not active while more laundry is being added.

Changing the programme

- 1. Press the DII button.
- 2. Select a different program.
- 3. Press the **>** button. This starts the new program from the beginning.

Cancel the programme

For programmes at high temperatures:

- 1. Press the DII button.
- 2. To cool down laundry: Select **Rinse**.
- 3. Press the DM button.

For programmes at low temperatures:

- 1. Press the DII button.
- 2. Select © Spin/ Drain (if only a drain cycle is required, set rpm (spin speed) to -0 -)
- 3. Press the DM button.

Programme end during rinse hold

---- © appears in the display panel and the indicator lamp of the DIII button flashes.

Continue the programme by selecting the **DII** button or a spin speed.

End the program by setting the program selector to ⑤ Spin/ ⑦ Drain (if only a drain cycle is required, set rpm (spin speed) to - 0 -) and then select the DIII button.

Programme end

End appears on the display panel and the D button indicator light is off.

Removing laundry/switching off the appliance

- 1. Open the loading door and remove the laundry.
- **2.** Turn the programme selector to **Off**. The appliance is switched off.
- Turn off the tap.Note: Not required for AquaStop models.

Notes

- Do not leave any items of laundry in the drum. They may shrink in the next wash or discolour another item.
- Remove any foreign objects from the drum and the rubber gasket – risk of rusting.
- Wipe the rubber gasket dry.



- Leave the loading door and detergent drawer open so that any remaining water can evaporate.
- Always wait until the programme ends as the appliance could still be locked. Then switch the appliance on and wait for it to unlock.
- At the end of the programme, the washing machine switches to energy saving mode. The displays go out. To exit energy saving mode, touch any button.

Sensors

Automatic load sensing

The automatic load sensing function adapts the water consumption ideally to each programme depending on the type of fabric and the load.

Unbalanced load detection system

The automatic unbalanced load detection system detects imbalances and ensures even distribution of the laundry by repeatedly starting and stopping drum spinning.

If the laundry is extremely unevenly distributed, the speed is reduced or the spin cycle is not performed for safety reasons.

Note: Place large and small items of laundry evenly in the drum. → Page 37

VoltCheck

The automatic voltage control system detects unauthorised voltage drops. The programme is interrupted.

Note: Whenever there is an undervoltage, the colon flashes on the display panel.



When the supply voltage is stable again, the programme continues running. The colon on the display panel no longer flashes.

If the interruption causes the programme to be extended, the dot on the display flashes.



The voltage control system is activated when a programme is started.

Note: If power failure occurs, the washing process is interrupted. The programme continues running when the power supply is restored.

Appliance settings

You can change the following settings:

- The volume of the information signals (e.g. at the end of the programme) and/or
- The volume of the button signals and/or
- Switch on or off the drum clean reminder*.

In order to change these settings you will need to activate the setting mode.



1/2/3/4... positions on the programme selector

depending on the model

en

Activating the setting mode

- 1. Turn the programme selector to position 1. The washing machine is switched on.
- 2. Press the DM button and, at the same time, turn the programme selector clockwise to position 2. Release the button.

The setting mode is activated and the preset volume for the information signals appears in the display panel (e.g. at the end of the programme).

Changing the volume

- To change the volume of the information signals, use the Finished in-time button while the programme selector remains at position 2.
- To change the volume of the button signals, rotate the programme selector to position 3. Use the Finished in-time button again to change the volume.



Switching on or off the drum clean reminder'

To switch on/off the drum clean reminder, rotate the programme selector to position 4. Use the Finished in-time button to switch the reminder on or off.





If the setting is activated, an acoustic signal is heard.

Exiting setting mode

You can now end the process and set

depending on the model

the programme selector to the off position. The settings are saved.

Cleaning and maintenance



Danger of death!

There is a risk of electric shock if you touch live components.

Switch off the appliance and pull out the mains plug.



Warning Risk of poisoning!

Toxic vapours can be produced by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

Caution!

Damage to the appliance

Cleaning agents that contain solvents, e.g. cleaning solvent, can damage surfaces and components in the machine.

Do not use cleaning agents that contain solvents.

Prevent detergent residue from building up and odours from forming by following these instructions:

Notes

- Ensure the room in which the washing machine is set up is well ventilated.
- Leave the door and detergent dispenser tray open slightly when the washing machine is not in use.
- Occasionally run a wash using the Cottons 60 °C programme and powder detergent.

Machine housing/control panel

- Wipe the housing and the control panel with a soft, damp cloth.
- Remove the detergent residue immediately.
- Do not clean with a water jet.

Drum

Use chlorine-free cleaning agents, do not use steel wool.

If there are odours in the washing machine, or to clean the drum, run the ©° Drum Clean 90 °C or © Cottons 90 °C program without laundry. Add washing powder.


Descaling

Descaling should not be necessary if the detergent is measured out correctly. However, if it is required, follow the manufacturer's instructions for the descaling agent. Suitable descalers can be obtained via our website or from our after-sales service.

Detergent drawer and housing

If the washing machine contains detergent or fabric softener residues:

- Pull out the detergent drawer. Press down the insert and fully remove the drawer.
- 2. To remove the insert: Push the insert upwards from below with your finger.



- Clean the detergent dispenser tray and insert with water and a brush, and dry it. Clean the inside of the housing as well.
- Fit the insert and lock it in place (push the cylinder onto the guide pin).
- **5.** Push in the detergent drawer.

Note: Leave the detergent drawer open so that any residual water can evaporate.

Detergent solution pump blocked

When you wash at high temperatures, the water gets very hot. If you come into contact with the hot water, you may be scalded.

Allow the detergent solution to cool down.


- 1. Turn off the water tap so that no more water can flow in and has to be drained via the drain pump.
- 2. Switch off the appliance. Pull out the mains plug.
- **3.** Open and remove the service flap.



Take the auxilary drain hose out of the holder.

Remove the locking cap and drain off the water into a suitable container.

Replace the locking cap and place the drain hose back in the holder.



 Carefully unscrew the pump cover; remaining water may leak out. Clean the interior, pump cover thread and pump housing. The impeller in the drain pump must be able to rotate.

Refit and screw on the pump cover. The handle must be in a vertical position.






Put the service flap back on, engage and close it.



Note: To prevent unused detergent from flowing into the outlet during the next wash: Pour 1 litre of water into compartment II and start the ⑤ Spin/ ∜ Drain/Empty programme (if only a drain cycle is required, set rpm (spin speed) to - 0 -).

The drain hose at the siphon is blocked

- 1. Switch off the appliance. Disconnect the mains plug.
- Loosen the hose clamp. Carefully remove the drain hose, residual water may leak out.
- 3. Clean the drainage hose and siphon connecting piece.




 Reattach the drainage hose and secure the connection using the hose clamp.

Filter in the water supply blocked

First, reduce the water pressure in the supply hose:


- 1. Turn off the tap.
- Select any program (except Rinse// Spin/Drain).
- Press the D button. Allow the program to run for approximately 40 seconds.
- **4.** Turn the program selector to **Off**. Pull out the mains plug.
- Clean the filter on the tap: Disconnect the hose from the tap. Clean the filter with a small brush.



6. For standard and Aqua-Secure models, clean the filter on the rear of the appliance:

Remove the hose from the rear of the appliance.

Use pliers to remove the filter and then clean it.



7. Connect the hose and check for leaks.



? Faults and what to do about them.

Emergency release

e.g. in the event of a power cut

The programme will continue running when the power supply has been restored.

However, if the laundry has to be removed, the washing machine door can be opened as follows:



Warning

Risk of scalding!

When you are washing at high temperatures, there is a risk of scalding if you come into contact with detergent solution and laundry.

If possible, leave it to cool down.

Warning Risk of injury!

You may injure your hands if you reach into the drum while it is turning. Do not reach into the drum when it is turnina.

Wait until the drum has stopped turning.

Caution! Water damage

Any escaping water may cause water damage.

Do not open the washing machine door if water can be seen through the glass.

- 1. Switch off the appliance. Disconnect the mains plug.
- 2. Drain the detergent solution.
- 3. Pull the emergency release downwards with a tool and release. The washing machine door can then be opened.



Information on the display panel

Display	Cause/remedy	
C lights up	 The temperature is too high. Wait until the temperature drops. The water level is too high. It is not possible to add laundry. Close the door immediately, if necessary. Press the D 00 button to continue the program. 	
© flashes	 Laundry may be caught. Open and close the door again and press the D 00 button. If necessary, push the door closed or remove some laundry and then push it closed again. If necessary, switch the appliance off and on again; set the program and make your individual settings; start the program. 	
ዶ lights up	 ■ Turn on the cold water tap fully, ■ Supply hose kinked/trapped, ■ The water pressure is too low. Clean the filter. → Page 34 	
E:18	 ■ The drain pump is blocked. Clean the drain pump. → Page 33 ■ The drain hose/drain pipe is blocked. Clean the drain hose at the siphon. → Page 34 	
E:23	There is water in the base plate, the appliance is leaking. Turn off the tap. Call the after-sales service! \longrightarrow Page 39	
E:32	flashes alternately with $\mathcal{E} \cap \mathcal{G}$ at the end of the programme.	
	Not a fault – the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.	
	Distribute small and large items of washing in the drum. If required, spin the laundry once more.	
C	The childproof lock is activated - deactivate it.	
The ॐ indicator light for the ॐ Drum Clean programme* flashes	 Run the ⊙° Drum Clean programme* or a 60 °C programme to clean and care for the drum and the outer tub. Notes Run the programme without laundry. Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates. Switching the information signal on/off → Page 31 	
: ① the 'Ready in' time flashes	Mains voltage is too low.	
. the 'Ready in' time flashes	Undervoltage in the wash program. The program duration is extended.	
Other displays	Switch off the appliance, wait for five seconds and then switch it on again. If the display appears again, call the after-sales service. \longrightarrow Page 39	

Faults and what to do about them.

Faults	Cause/remedy
Water is leaking from the machine.	Attach the drain hose correctly or replace it.Tighten the threaded joint on the supply hose.
Water is not flowing in. Detergent is not being dispensed.	 ■ Have you pressed the DOD button? ■ Is the tap turned on? ■ Could the filter be clogged? Clean the filter. → Page 34 ■ Is the supply hose kinked or trapped?
The door will not open.	 The safety function is active. Do you want to stop the programme? → Page 30 Is the ∽ childproof lock activated? Deactivate it. Is selected (Rinse Stop = no final spin)? → Page 30 Can the door only be opened by the emergency release? → Page 35
The programme will not start.	 Have you pressed the D button? Is Finished in-time selected? Is the door closed? Is the childproof lock activated? Deactivate it. → Page 29
The drum briefly jerks or judders after the programme has started.	Not a fault – the internal motor test may cause the drum to jerk or judder briefly when the wash programme starts.
The water is not draining.	 Is selected (Rinse Stop = no final spin)? → Page 30 Clean the drain pump. → Page 33 Clean the drain pipe and/or the drain hose.
Water is not visible in the drum.	Not a fault – the water is below the visible area.
The spin result is not satisfactory. Laundry is wet/too damp.	 Not a fault – the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Distribute small and large items of laundry evenly in the drum. Is Anti-crease (depending on the model) selected? Is the selected speed too low?
The appliance restarts the spin cycle several times.	Not a fault – the unbalanced load detection system is adjusting an imbalance.
The programme is taking longer than usual.	 Not a fault – the unbalanced load detection system is adjusting an imbalance by repeatedly redistributing the laundry. Not a fault – the foam detection system is active – a rinse cycle has been activated.
The length of the programme changes during the wash cycle.	Not a fault – the programme sequence is optimised for the specific washing process. This may change the length of the programme shown on the display panel.
Water remaining in the care product compartment & .	 Not a fault – the effectiveness of the care product is not affected. Clean the insert if necessary.

Faults and what to do about them. en

Faulte	Causalvamadu
Faults	Cause/remedy
Odours in the washing machine.	Depending on the model, run the 🕒 Drum Clean90 °C or 🏗 Cottons90 °C program without laundry.
	Add standard washing powder or a detergent that contains bleach.
	Note: To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents intended for woollens or delicates.
Foam may also be leaking	Have you used too much detergent?
from the detergent drawer.	Mix one tablespoon of fabric softener with 1/2 litre of water and pour it into compartment II (not suitable for outdoor clothing, sportswear or items made with down).
	Use less detergent in the next wash cycle.
Loud noises, vibrations and machine "wandering" during the spin cycle.	 Is the appliance level? Make the appliance level. → Page 16 Are the appliance's feet secured? Secure the appliance's feet. → Page 16 Have the transport braces been removed? Remove the transport braces. → Page 13
The display panel/indicator lights do not work while the appliance is running.	 Has there been a power failure? Have the fuses blown/has the circuit breaker tripped? Switch on the circuit breaker/replace the fuses. If the fault occurs repeatedly, call the after-sales service.
There is detergent residue on the laundry.	 Some phosphate-free detergents contain water-insoluble residue. Select W Rinse or brush the laundry after washing.
The © symbol is lit in the display panel when paused.	 The water level is too high. It is not possible to add laundry. Close the door immediately if necessary. Press the DOD button to resume the programme.
The © symbol in the display panel is off when paused.	The door is unlocked. It is possible to add laundry.

If you cannot rectify a fault yourself (after switching the machine off and then on again) or a repair is required:

Switch off the appliance and pull the mains plug out of the socket.

Turn off the tap and call the after-sales service.

After-sales service

If you cannot rectify a fault yourself, contact customer services. → Cover page

We will always find an appropriate solution in order to avoid unnecessary visits by engineers.

Please give customer services the product number (E no.) and the production number (FD) of the appliance.

E-Nr	FD

F no. Product number FD Production number

You can find this information *depending on the model:

On the inside of the door*/in the opened service flap* and on the rear of the appliance.

Trust the expertise of the manufacturer.

Contact us for assistance. By doing so, you will ensure that the repairs are carried out by trained service personnel using genuine spare parts.



Technical data

Dimensions:

84.8 x 60 x 44.5 cm (height x width x depth)

Weight:

65 ka

Mains connection:

Nominal voltage 220-240 V, 50 Hz Nominal current 10 A

Nominal power 2300 W

Water pressure:

100-1000 kPa (1-10 bar)

Power consumption when switched off:

0.12 W

Power consumption when ready for use (on standby):

0.48 W

Aqua-Stop warranty

Only for appliances with Aqua-Stop

In addition to warranty claims against the vendor based on the purchase agreement and to our appliance warranty, we will provide compensation under the following conditions:

- If water damage is caused due to a fault in our Aqua-Stop system, we will compensate domestic customers for the damage caused.
- 2. The liability guarantee is valid for the service life of the appliance.
- 3. It is a prerequisite of all warranty claims that the appliance with Aqua-Stop must have been installed and connected correctly in accordance with our instructions; this also includes a correctly fitted Aqua-Stop extension (genuine accessories). Our warranty does not cover defective feed lines or fittings leading to the Aqua-Stop connection at the tap.
- 4. Appliances with Aqua-Stop do not need to be supervised during operation, nor secured afterwards by turning off the tap. The tap only needs to be turned off if you are away from home for a long period, e.g. for several weeks' holiday.









Advice and repair order in the event of faults

0344 892 8979 (Calls charged at local or mobile rate.) GB ΙE

01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

Robert Bosch Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY

9001390372 (9804)