Electrolux 600 SmartSelect FI with 14 Settings 44 dB(A)/B

E62LA201S



Powerful cleaning, easy to load baskets

A multi-angled spray arm gives the 600 series extra spray coverage. Easy to load, with spacious baskets and foldable rows. No-fuss, time-based cycle selection.

Product Benefits & Features



Just select cycle time. No need to choose between programmes
An easier way to use your dishwasher. QuickSelect Connect display shows how energy use changes, depending on the cycle length. Move the slider to choose time, and see the energy graph change. Loading, program, and maintenance tips in the app.



Double-rotating spray arm cleans from all directions
360Clean spray arm thoroughly cleans your dishes with powerful, double-rotating spray coverage. Even closely placed or larger dishes receive deep cleaning no matter where they are loaded. And all without using any more water or energy.



Versatile drawer with knife holder fits cutlery and utensils
The FlexiMax drawer with knife holder is designed to fit cutlery and many different shapes and sizes of utensils. The customisable dividers and deep drawer mean large or awkwardly shaped items can be loaded with ease.



Anti-slip, rubber spikes for secure glass care
Rubber, anti-slip SoftSpikes® protect your glassware. They gently hold items in place to reduce the risk of chips and scratches due to collisions.



A light shines onto the floor to show the dishwasher is running
LightOnFloor® shines a white light onto the floor whilst a cycle is under way. The light turns off when the cycle is complete and the dishes are ready to be unloaded.

- LightOnFloor
- Touch control for programs and functions selection
- Delay Start
- Indications for salt and rinse aid
- AirDry
- Auto Off function
- Upper basket with 2 rows of fixed tines, 2 Soft Spikes, Foldable cup shelves, plastic handle Electrolux
- Lower basket with 4 rear foldable tines, Low round rack frame, Plastic handle
- Options: GlassCare, PowerBoost
- Dishwasher programmes: 120 Minutes, 60 Minutes, 90 Minutes, AUTOClean, ECO, MachineClean, QuickClean, QuickRinse

Electrolux

Electrolux 600 SmartSelect FI with 14 Settings 44 dB(A)/B

E62LA201S

Product Specification

Installation	FI
Rated capacity E20	14
Energy efficiency class, legal (E20)	A
Airborne acoustical noise emissions, dBA re 1 pW	44
Door colour	None
Dimensions_Dishwasher_FSBU_DK	820-900x600x550
Number of programs	8
Number of temperatures	3
Dimensions HxWxD in mm	818x596x550
Airborne acoustical noise emission class	B
Depth open door	1200
Connectivity	Yes
Nordic_DW_CutleryType	Cutlery drawer
Nordic_DW_QuickSelect	Level 2
Nordic_DW_SoftSpikes	2 SoftSpikes holders
Nordic_DW_GlassCare2G	No
Indicator on Floor	LightOnFloor
Interior light	No
Nordic_DW_DoorFitKit	No
Cleaning performance index3 digitE20	1.121
Drying performance index 3 digitE20	1.061

Weighted average energy consumption / 100 cycles, kWh (E20)	54
Water consumption / cycle lE20	9.5
Hinges	Sliding up to 10kg
Connected load, W	1950
Cord length, m	1.5
Outlet hose length, cm	150
Required fuse (A)	10
Inlet hose length, cm	150
Inlet hose type	Aqua control
Anti-flood device	Floating switch
Water supply	Cold or Hot
Upper basket, Level 1, max	190
Upper basket, Level 2, max	140
Lower basket, Level 1, max	270
Lower basket, Level 2, max	315
Upper spray arm	Standard spray arm
Lower spray arm	360Clean
Options	GlassCare, PowerBoost
Options available only through the App	ExtraDry, ExtraHygiene, ExtraQuiet, GlassCare, HalfLoad, PowerBoost
Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Installation in height	None
Nordic_DW_DoorPanelHeight	645-776